

Farm Class Rules

1. Class speed limit is 3.5 MPH.
2. Tractors must have a working stock air cleaner.
3. Tractors must have stock carburetors. Tractors must have stock engine and components, or manufacturer's replacement for that model.
4. Tractors must have and pull from a stock draw bar, no more than 20 inches to top and at least 18 Inches from rear of draw pin hole to center of axle. Any clevis or bolted hitch ring can be used. Factory drawbar can be modified for length and height adjustment, but must retain factory look. Farmall can pull from clevis/hitch on factory hoop.
5. Tractors will run at stock engine speeds. Adjusting governor between stock and improved is not allowed.
6. Tractors will have standard diameter rims. Cut tires are not allowed.
7. Tractors can pull in more than one stock class by adding weights.
8. Front end loaders or belly mowers can be on tractor
9. Gear changing (T/A shifting) is not allowed during pull.
10. Farm class tractors are only allowed to pull in Farm classes. Farm Class tractors are not allowed to enter improved classes (unless at Sponsors Request).

Weight classes for Farm Class: 3000-3500-4000-4500-5500-6500-7500